



\* Place HI-Chairs as far from gallop as is practical

For <sup>GIRDERS</sup> W-BMS, Prestressed Concrete Brms

Keep Brms @ 4' Center Under Transverse Bar